



Banana Moon Maintenance Guide

The Banana Moon is a wonderful and fun addition to AGATI's Children's collections. This remarkable, comfortable and versatile chair can last a lifetime by performing routine check-ups to make sure all support rods and fasteners are secure.

The Banana Moon is made to withstand usage by small adults and children, only. Because the Banana Moon moves while in use, bolts may loosen over time due to usual seasonal swelling and drying of the wood panels.

When you receive the rocker, you receive a spanner wrench which is a "y"-shaped tool with two pins. This tool is used to tighten the elevator style/washer head bolts. Note: before tightening each of the fasteners, apply the provided medium strength liquid Loctite 242 thread lock to the threads of each fastener. This helps prevent the fasteners from vibrating loose over time. If you have misplaced the provided loctite you can purchase this from any hardware store.

Please have maintenance check the tightness of these bolts *ONCE EVERY TWO MONTHS* to make sure all the fasteners are tight.

Remember this product has weight restrictions and is mainly designed for children and small adults. Applying weight over 150 lbs may result in damage to the product.

Following these simple instruction will help insure a long life of enjoyment of the AGATI Banana Moon Rocker.

Sincerely,
Agati Furniture